


# ***Shark*** STEAMPICKUP

---

**SD200  
SERIES**

---



To view **HOW-TO VIDEOS**  
scan QR Code.

# IMPORTANT SAFETY INSTRUCTIONS

FOR HOUSEHOLD USE ONLY. READ ALL INSTRUCTIONS BEFORE USING THIS 3-IN-1 CLEANER

## WARNING

To reduce the risk of fire, electric shock, injury, or property damage:

**GENERAL WARNINGS: WHEN USING YOUR SHARK® SteamPickUp, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:**



**WARNING:** Danger of scalding. The steam emitted from the SteamPickUp is very hot and may cause scalding. Please use caution when using the SteamPickUp.



**WARNING:** Keep SteamPickUp away from children.



**WARNING:** Children should be supervised to ensure that they do not play with the appliance.

- 1. DO NOT** leave the SteamPickUp unattended when plugged in. **ALWAYS** unplug the power cord from the electrical outlet when not in use and before servicing.
- 2. DO NOT** use with damaged cord or plug. If SteamPickUp is not working as it should or has been dropped, damaged, left outdoors, or dropped into water, return it to SharkNinja Operating LLC for examination and repair. Incorrect reassembly or repair can cause a risk of electrical shock or injury when used.
- To protect against a risk of electric shock, **DO NOT** immerse the SteamPickUp in water or any other liquids.
- 4. DO NOT** handle the plug or SteamPickUp with wet hands or operate it without wearing shoes.
- 5. DO NOT** pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. **DO NOT** run SteamPickUp over cord. Keep cord away from heated surfaces.
- 6. DO NOT** unplug by pulling on power cord. To unplug, grasp the plug, not the power cord.
- Unplug before servicing.
- 8. ALWAYS** make sure the SteamPickUp is **UNPLUGGED** when not in use

- 9. NEVER** fill the SteamPickUp or attach the mop head when the SteamPickUp is plugged into an electrical outlet. Unplug from the electrical outlet and allow to cool before you fill the mop.
- When cleaning the exterior of the SteamPickUp, unplug the power cord from the electrical outlet and clean the SteamPickUp with a dry or damp cloth. **DO NOT** pour water or use alcohol, benzene, or paint thinner on the SteamPickUp.
- To avoid circuit overload, **DO NOT** operate another appliance on the same socket (circuit).
- To avoid scalding injuries, **ALWAYS** unplug and allow the SteamPickUp to cool before removing tanks/brush-roll.
- This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.

### USE WARNINGS



- When in use. **NEVER** turn the SteamPickUp on its side.
- Use the system only for its intended use
- 16. DO NOT** use for space-heating purposes.
- 17. DO NOT** use outdoors.
- 18. DO NOT** allow the SteamPickUp to be used by children. Close attention is necessary when used near children, pets or plants
- Use only as described in this instruction manual.
- Use only manufacturer's recommended accessories.

# SAVE THESE INSTRUCTIONS


- 21. DO NOT** put any objects into the steam nozzle openings.
- 22. DO NOT** put hands or feet under the steam. It gets very hot.
- Use **ONLY** on flat, horizontal surfaces. **DO NOT** use on walls, counters, or windows.
- 24. DO NOT** use on leather, wax-polished furniture, synthetic fabrics, velvet, or other delicate, steam-sensitive materials.
- 25. DO NOT** add cleaning solutions, scented perfumes, oils, or any other chemicals to the water used in the SteamPickUp as this may damage it or make it unsafe for use. If you live in a hard-water area, we recommend using distilled water in your SteamPickUp.
- You can release the brush-roll after you have unplugged the SteamPickUp and allowed it to cool.
- Extreme caution should be exercised when using the SteamPickUp to clean stairs.
- 28. NEVER** use SteamPickUp without the brush-roll or dirty water tank attached.
- Keep your work area well lit.
- Store SteamPickUp indoors in a cool, dry place.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- 32. DO NOT** carry the SteamPickUp while in use.
- The steam emitted from the steam mop is very hot and may cause scalding. Please use caution when using the SteamPickUp.
- 34. DO NOT** use on unsealed wood or unglazed ceramic floors. On surfaces that have been treated with wax and on some unwaxed floors, the sheen may be removed by the heat and steam action.
- 35. ALWAYS** test an isolated area of the surface to be cleaned before proceeding. We also recommend that you check the use and care instructions from the floor manufacturer.
- 36. DO NOT** scrub any one area for an extended period.
- 37. DO NOT** use the SteamPickUp without the brush-roll and adding water to the water tank. When you use the SteamPickUp for the first time, it might take longer than the normal 30 seconds to start steaming.
- To prolong the life of your SteamPickUp, we recommend using distilled water. Add **ONLY** water to the tank. Chemicals or cleaning solutions (including vinegar) may damage the SteamPickUp and could be unsafe for you and your family.
- The liquid or steam must not be directed towards equipment containing electrical components, such as the interior of ovens. Dispose of contents/ container with a licensed waste disposal site in accordance with the requirements of the local waste disposal authority.
- Keep the appliance out of reach of children when it is energized or cooling down.
- A hazard may occur if the appliance runs over the supply cord.

## WHAT'S INCLUDED


- A** Handle
- B** Pole
- C** Power Button
- D** Clean Solution Tank
- E** Debris Tank
- F** Brush-roll
- G** Power Cord
- H** Nozzle Cover
- I** Storage Dock
- J** Pole and Brush-roll Storage



## ASSEMBLY




**1.** Align the **pole** with the opening in the **main body** and insert firmly until it clicks into place. To remove the handle, firmly press the button located on the rear side of the body and pull the pole upwards. This can then be stored in the pole mount located on the dock.




**2.** Place the SteamPickUp on the floor near a wall outlet and plug in the cord. The LEDs on the main body will illuminate when plugged in. Make sure all the parts are fully secure, such as the brush-roll, dirty water tank, and clean water tank.


## STORAGE



**1.** When ready to store, place the in a suitable location and place the unit onto the dock. The pole and brush-roll can also be stored separately on the dedicated storage points on the side of the main unit dock.




**2.** For compact storage, remove the wand (pressing the button on the rear of the body to do so) and locate into the wand storage location on dock. This allows the unit to be stored neatly under lower surfaces as may be required.




**3.** The hook on the rear of the body can be used to store the power cord.

## USING YOUR STEAMPICKUP


### SELECTING A MODE




#### MODES:



**IN USE:**  
(LED LIGHTS ON, NUMBER OF LEDS ILLUMINATED WILL VARY PER MODE)




**STANDBY:**  
(LED LIGHTS FLASHING)



**HIGH:**  
THE STEAM FLOW RATE WILL BE RUNNING AT HIGHEST PERFORMANCE



**MEDIUM:**  
THE STEAM FLOW RATE WILL BE RUNNING AT A MEDIUM LEVEL AND SPEED.



**LOW:**  
THE STEAM FLOW RATE WILL BE RUNNING AT A SLOW PACE AND LOWEST STEAM POWER




**ERROR MESSAGES:**  
(REFER TO ERROR MESSAGE SECTION)

**NOTE:** When plugged in, the unit will not release steam until it is leaned back and is in use.

The Shark SteamPickUp is a Wet Cleaner that can both pick up and mop your hard floors. It has the ability to clean up both dry and wet debris to your liking. With a rotating brush-roll and a steamer you can both sweep and mop your household.

## USING YOUR STEAMPICKUP

### FILLING THE CLEAN SOLUTION TANK



1. Pull out tank and unscrew cap.
2. Pour water to **WATER** fill line.
3. Re attach the cap ensuring it is secure, then re-insert the tank, clicking it in to place.

**NOTE:** Without sufficient water supply in the clean water tank, the unit will not produce steam.


### TO SANTISE FLOORS

1. Insert a clean brush-roll into SteamPickUp
2. Plug in the unit, tilt the handle down towards you, and press the mode button to select the MEDIUM setting. The brush-roll will then start spinning.
3. Wait at least 20 seconds for the unit to begin producing steam.
4. To ready the unit for sanitisation, start cleaning with a forward and backward motion on an appropriate sealed hard floor surface. After three minutes, your unit will be ready to sanitise.
5. Move the floor nozzle slowly and evenly over the area to be sanitised while applying continuous downward pressure. Slowly repeat, making sure to cover the entire area to be sanitised with at least 15 strokes.


\*Sanitisation studies were conducted under controlled test conditions. Be certain to follow all directions for use carefully to fully sanitise with mop head set in the NORMAL mode.

## USING YOUR STEAMPICKUP


### HOW TO USE YOUR STEAMPICKUP



1. Power on your SteamPickUp by first plugging in a wall outlet.



2. Set what mode you would like to use your SteamPickUp in.



3. Kick down nozzle to turn on SteamPickUp, clean according to cleaning tips below.


### CLEANING TIPS

<b>Top Tip</b>	For the most effective debris collection and mopping, pass through the cleaning area in a forwards motion (cleaning with the unit moving away from your body).
<b>Dry Debris</b>	Slowly pass over debris to let into the debris chamber. The brush-roll should push all content into the chamber. If debris is not being picked up, let the SteamPickUp stay over area in same place for a couple seconds.
<b>Wet Debris</b>	Slowly pass over the cleaning area to allow the brush-roll to pick up the debris. If the debris is clumped or wet, take a longer pass to make sure the brush-roll can offload all of the debris into the chamber. Repeat this process in the instance that any debris is not captured in the first pass.
<b>Stain Cleaning</b>	Subject to the type of stain, you can dilute/saturate the stained area to effectively lift stains. Hold in place for 2-3 seconds first and then pass the nozzle over the area multiple times until the stain is fully removed. <b>Normal dry stains:</b> Hold in place for 5 seconds over stain then pass over until fully gone. <b>Sticky/thick stains:</b> Hold in place for 10 seconds, then pass over until fully gone. (Repeat steps if stain is still not taken out or is not wet or saturated enough)
<b>Mopping</b>	Continuously pass through a cleaning area working from back to front motion over the floor surface, increasing the steam level to increase saturation level.
<b>Edge Cleaning</b>	When edge cleaning, run the nozzle head parallel to the edge surfaces using the left and right sides of the nozzle to get as close as possible for maximum pick up.


**NOTE:** If your floors are cloudy, streaky, or spotty after cleaning, it may be due to accumulated soap or grease residue, follow maintenance guide for best practice.

## MAINTAINING YOUR STEAMPICKUP


### DISASSEMBLY & DEBRIS DISPOSAL




1. Take off nozzle cover by pinching the two tabs together.



2. Remove debris tank by lifting out of the floor nozzle using the handle.




3. a. Remove the brush-roll by pulling upward on the tab until a 'click' is heard.  
b. Slide the brush-roll out horizontally.



4. a. Dispose of solids first.  
b. Next, open one pull tab & pour out the dirty liquid.

## MAINTAINING YOUR STEAMPICKUP

### RINSING AND REASSEMBLY



**5.** Rinse all parts with warm water and soap. Leave out to fully air dry for 24 hours. Open the rotating catch plate as shown to access and rinse any additional debris caught within the lid.

**6.** Insert all parts securely  
back into unit. Make sure all parts click:


- a.** brush-roll
- b.** debris tank
- c.** nozzle cover

**NOTE:** Only reassemble once all components are dry by reversing disassembly steps. Ensure the tabs on the debris tank are sealed and all other components are correctly secured in place before next use.

**NOTE:** These parts are NOT dishwasher safe.  
**NOTE:** Maintain the brush-roll after each use to ensure best cleaning performance


### ERROR MESSAGES

#### FULL DEBRIS TANK




All lights blinking  
**WHITE & RED**

#### COVER NOT ATTACHED



Alternating blinking  
**WHITE & RED**

#### BRUSH-ROLL JAM



**SOLID RED**  
(no blinking)

### CHECKING FOR BLOCKAGES

If you run over a hard or sharp object or notice a noise change while using your unit, check for blockages or objects caught in the brush-roll or nozzle chamber.

- 1.** Turn off the power.
- 2.** Remove the nozzle cover, brush-roll, and debris tank.
- 3.** Check the openings and remove all debris.
- 4.** When finished, reinstall the brush-roll and the debris tank and replace the cover.

## TROUBLESHOOTING

PROBLEM	POSSIBLE REASONS & SOLUTIONS
<b>The SteamPickUp isn't producing any steam.</b>	<ul style="list-style-type: none"> <li>• The unit should be securely plugged into an electrical outlet. Check your fuse or circuit breaker or try a different outlet.</li> <li>• Make sure the water tank is full, the unit is plugged in, and the mode button is illuminated.</li> <li>• If the settings lights are off, try a different electrical outlet.</li> <li>• If the settings lights are blinking, press the mode button to select a steam setting.</li> <li>• If the settings lights are illuminated steadily, wait 30 seconds for the unit to warm up.</li> </ul>
<b>The SteamPickUp is producing intermittent steam.</b>	<ul style="list-style-type: none"> <li>• This is normal, for more consistent steam, select the MEDIUM setting. Also make sure the water tank is full.</li> </ul>
<b>I can't select a steam setting.</b>	<ul style="list-style-type: none"> <li>• Make sure the unit is plugged in and the settings lights are flashing.</li> </ul>
<b>Floors are cloudy, streaky, or spotty after cleaning.</b>	<ul style="list-style-type: none"> <li>• The brush-roll might be dirty. Remove brush-roll &amp; clean with warm water and soap.</li> <li>• Due to accumulated soap or grease residue, the floor may require several cleans with the SteamPickUp.</li> <li>• Overfilling the Clean Solution Tank with more Shark Hard Floor Multisurface Cleaner than instructed, may cause streaking &amp; foaming.</li> </ul>
<b>Debris and dirty water is not being picked up</b>	<ul style="list-style-type: none"> <li>• The debris tank might be full. Remove debris tank and dispose of all solids and liquids.</li> <li>• Make sure the brush-roll and debris tank is clear from blockage. Make sure to fully check those and discard any dirt.</li> <li>• Debris might be extremely lightweight. Lightly saturate the debris and try again.</li> </ul>
<b>The SteamPickUp is not turning on</b>	<ul style="list-style-type: none"> <li>• Make sure that the plug is fully secure and plugged into the outlet correctly. If the lights are not on or flashing of any kind when plugged in.</li> </ul>

Contact Customer Service at +44 (0)800 862 0453 or visit [sharkclean.co.uk](http://sharkclean.co.uk).

## THREE (3) YEAR LIMITED GUARANTEE

When a consumer buys a product in the UK, they get the benefit of legal rights relating to the quality of the product (your "statutory rights"). You can enforce these rights against your retailer. However, at Shark® we are so confident about the quality of our products that we give the original product owner an additional manufacturer's guarantee of up to three years (1 year standard plus 2 on registration). These terms and conditions relate to our manufacturer's guarantee only - your statutory rights are unaffected.

The conditions below describe the prerequisites and scope of our guarantee. They do not affect your statutory rights or the obligations of your retailer and your contract with them.

The Lithium ION power pack is not covered by the 3 year guarantee (see battery guarantee on next page)

### Shark® Guarantees

A household appliance like a steam cleaner constitutes a sizeable investment. Your new machine needs to work properly for as long as possible. The guarantee it comes with is an important consideration - and reflects how much confidence the manufacturer has in its product and manufacturing quality.

Every Shark® machine comes with a free parts and labour guarantee. Our customer service helpline (0800 862 0453) is open from 9.00am to 6.00pm Monday - Friday. It's free to call, and you'll be put straight through to a Shark® representative. You'll also find online support at [www.sharkclean.co.uk](http://www.sharkclean.co.uk)

### How do I register my extended Shark® guarantee?

You can register your guarantee online within 28 days of purchase. To save time, you'll need the following information about your machine:

- Date you purchased the machine (receipt or delivery note)

To register online, please visit [www.sharkclean.co.uk/register-guarantee](http://www.sharkclean.co.uk/register-guarantee). Products purchased directly from Shark® are automatically registered.

### IMPORTANT

- Both the 1 years and the extended 2 years guarantee will only cover your product from the date of purchase.
- Please keep your receipt at all times. Should you need to extend your guarantee we will need your receipt to verify the information you have supplied to us is correct. The inability to produce a valid receipt may invalidate the extension.

### What are the benefits of registering my free Shark® guarantee?

When you register your guarantee we'll have your details to hand if we ever need to get in touch. If you further agree to receive communications from us, you can also receive tips and advice on how to get the best out of your Shark® steam cleaner and hear the latest news about new Shark® technology and launches.

If you register your guarantee online, you'll get instant confirmation that we've received your details.

### How long are new Shark® machines guaranteed for?

Our confidence in our design and quality control means that your new Shark® steam cleaner is guaranteed for a total of up to three years (1 years plus 2 years on registration).

### What is covered by the free Shark® guarantee?

Repair or replacement (at Shark's discretion) of your Shark® machine, including all parts and labour. A Shark® guarantee is in addition to your legal rights as a consumer.

### What is not covered by the free Shark® guarantee?

1. Blockages - for details of how to unblock your 3-in-1 steam cleaner, please refer to the instructions.
2. Normal wear and tear such as brush bar, fuse, belt, batteries, hose etc.
3. Accidental damage, faults caused by negligent use or care, misuse, neglect, careless operation or handling of the steam cleaner which is not in accordance with the Shark® instructions supplied with your machine.
4. Use of the steam cleaner for anything other than normal domestic household purposes.
5. Use of parts not assembled or installed in accordance with the operating instructions.
6. Use of parts and accessories which are not Shark® Genuine Components.
7. Faulty installation (except where installed by Shark®).
8. Repairs or alterations carried out by parties other than Shark® or its agents.
9. The Lithium ION power pack battery. Please see next page for battery guarantee.

### What happens when my guarantee runs out?

Shark® does not design products to last for a limited time. We do appreciate that there may be a desire for our customers to want to repair their steam cleaners after the guarantee has lapsed. In this case please contact our Freephone customer service help line and ask about our out of guarantee programme, on 0800 862 0453.

### Where can I buy genuine Shark® spares and accessories?

Shark® spares and accessories are developed by the same engineers who developed your Shark® steam cleaner. You'll find a full range of Shark® spares, replacement parts and accessories for all Shark® machines at [www.sharkclean.co.uk](http://www.sharkclean.co.uk).

Please remember that damage caused by use of non-Shark® spares is not covered under your guarantee.

## ORDERING REFILLS & PARTS

Replace the brush-roll every 6 months.

Only use water with the Shark SteamPickUp.

To order brush-rolls, filters, please visit [sharkclean.co.uk](http://sharkclean.co.uk) or scan the QR code.



### REGISTER YOUR PURCHASE



[registryourshark.com](http://registryourshark.com)



### RECORD THIS INFORMATION

Model Number: \_\_\_\_\_

Date Code: \_\_\_\_\_

Date of Purchase: \_\_\_\_\_  
(Keep receipt)

Store of Purchase: \_\_\_\_\_

### TECHNICAL SPECIFICATIONS

Model: SD200UK 26


220-240V-, 50-60Hz, 1230W

**NOTES**

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....





To view **HOW-TO VIDEOS**  
scan QR Code.



**PLEASE READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.**

This Instruction Booklet is designed to help you get a complete understanding of your new SteamPickUp Steam Cleaner.

**SharkNinja Europe Ltd,**  
1st/2nd Floor Building 3150, Thorpe Park,  
Century Way, Leeds, England, LS15 8ZB  
+44 (0)800 862 0453  
[www.sharkclean.co.uk](http://www.sharkclean.co.uk)

**SharkNinja Germany GmbH**  
Rotfeder Ring 9  
60327 Frankfurt am Main  
Germany  
[www.sharkclean.eu](http://www.sharkclean.eu)

Illustrations may differ from actual product. We are constantly striving to improve our products, therefore the specifications contained herein are subject to change without notice.

SHARK is a registered trademark in the United Kingdom of SharkNinja Operating LLC.